COLORS
EARBUDS

Colors TWS Earbuds
User's Manual



HS7508WT



HS7508VT



HS7508BK

Introduction

It is a great pleasure to know you have selected Unno Tekno as your new source of audio experience, where we take technology above and beyond. The TWS Colors earbuds is a new trending style which comes with a transparent casing design & multicolor charging effect. Additionally, it features a LED battery status display for the case and earbuds.

Jam on the go for over 20 hours with style on a single charge! To learn more about these earbuds or to find other outstanding products like these, visit us at **www.unnotekno.com**.

Warning

Always keep your volume at a safe level below 85 decibels. Listening to any audio at high volume for a long time could cause permanent damage to your hearing.

FCC Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the two following conditions:
1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Support

If you require additional help, please don't doubt to contact us at **support@unnotekno.com** or visit **www.unnotekno.com**.

Legal Notice

Names, logos, and trademarks belong to their respective owners. Siri, Google Assistant, Alexa, etc., are owned by their parties. Product appearance and functions may vary. © 2024 Unno Tekno LLC. All rights reserved.

Charging Instructions


1. Fully charge your earbuds before using them for the first time.

2. To charge the earbuds, insert them into the charging case. The red LED on each earbud will stay on while charging. Once fully charged, the LED will turn off. You can also check the battery status on the front display.

3. To charge the case, insert the supplied Type-C cable into the corresponding charging port. Connect the other end to a USB power source (do not use a PD charger). You will get a temporary multicolor lighting effect on the case once a charger is detected. Using a standard 5V/1A charging current it can take up to 2 hours to fully charge the case.

4. Fully charged earbuds can work for up to 7 hours, and a fully charge case can provide up 3.3 additioanl charging cycles for up to 23 hours of combined playing time. Please note the time may vary based on your usage.

5. To avoid permanent damage to your earbuds, do not attempt to charge it using any accessory other than those that were originally included or recommended.



Legend

1. Left earbud/Multifunction button
2. Right earbud/Multifunction button
3. Left earbud charging compartment
4. Right earbud charging compartment
5. Left earbud battery level indicator
6. Right earbud battery level indicator
7. Charging case battery level indicator
8. Charging Type C port (bottom)

Inside the Box

- Colors Earbuds
- Charging cable
- Lanyard
- Ear tips spare set (2)
- User's manual

Basic Operation

1 Earbuds On/Off

To manually power on/off the earbuds, take them out from the charging case and press the multifunction button on each earbud for 3-5 seconds. Otherwise, you may insert them into the charging case, and they will power off. Once removed from the charging case, they will power on again.

2 Pairing the earbuds to a phone (first time)

After removing the earbuds from the charging case, they will automatically enter pairing mode. The status light will flash between blue and red, and a confirmation message will be played. Turn on your phone's BT and select HS7508 from the list of available devices.

Once the connection is established, you will hear a confirmation message, and the status light will turn blue and then go off.

3 Track management

To pause or resume the playback of a music track, tap once on either earbud's multifunction button. To go to the next track, tap the right earbud's multifunction button twice. To go to the previous track, tap the left earbud's multifunction button twice. To adjust the volume, triple tap the left earbud's multifunction button to lower the volume or right earbud's multifunction button to raise the volume.

4 Call management

To answer an incoming call, briefly tap either earbud's multifunction button and briefly press it again to hang up. Long-press either earbud's multifunction button to reject the call.

5 Smart assistant (compatible phones)

To activate your device's default smart assistant (such as Siri, Alexa, or Google Assistant), press and hold the multifunction button on either earbud for about 3 seconds. You will hear a confirmation tone, and the smart assistant will wake up on your device.

Technical Specifications

- BT version: 5.3
- BT profiles: HFP, A2DP, & AVRCP
- BT working range (ft): 30
- Li-Ion battery (mAh):
  40 earbuds / 330 charging case
- Charging/playing time (h): 2/7
- Charging cycles: up 3.3 (80% efficiency)
- Controls: Multifunction capacitive button
- Frequency response (Hz): 20-20k
- Impedance (Ω): 32 +/-15%
- Output power (mW): 5
- Driver diameter (in): 0.3
- Microphone sensitivity (dB): -38 +/-3
- Input power (VDC/A): 5/1
- Earbud weight (oz): 1.48