LUXPRO



Quick Setup Guide

HS7511

Introduction

It is a great pleasure to know you have selected Unno Tekno as your new source of audio experience, where we take technology, above and beyond. Our new LuxPro TWS earbuds come with a premium fabric style casing and LED battery status display. The earbuds are comfortable and boast superior sound quality.

To learn more about this or other outstanding products, please visit us at **www.unnotekno.com**.

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference. 2. This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Support

For additional help, contact us at **support@unnotekno.com**.

Legal Notice

Google Assistant™, Siri™, and Alexa™ are trademarks of their respective owners. This product is compatible with these voice assistants but is not affiliated with or endorsed by Google LLC, Apple Inc., or Amazon.com, Inc. All trademarks are the property of their respective owners.

Images and colors may differ from actual product. © 2024 Unno Tekno LLC. All Rights Reserved.

Safety Recommendations

- Please read this manual carefully before using the device for the first time; Failing to do so may result in permanent damage, severe personal injuries, and voiding of the warranty.

- Always keep the volume below 85 decibels to prevent permanent hearing damage from prolonged exposure to high sound levels.

- To prevent the risk of a shortcircuit while the device is charging, keep it away from water or moist environments.

- When plugging in the device, avoid pulling or stressing the charging cable, and place it where it won’t cause tripping.

- Keep the device away from heat sources or direct sunlight to prevent overheating.

- To prevent electrical hazards and avoid voiding your device's warranty, do not attempt to open or modify the device. If you require to perform any service to it, please refer to a certified professional.

Charging Instructions

Fully charge your earbuds before first use.


Place the earbuds in the charging case; the red LED will stay on while charging and turn off when fully charged. The front display shows the battery status, with L/R icons blinking during charging and turning solid when fully charged.

To charge the case, use the supplied Type-C cable with a USB power source (avoid PD chargers). The front display indicates the battery level from 0% to 100%, and a full charge takes up to 2 hours with a 5V/1A charger.

When fully charged, the earbuds provide up to 4 hours of playback at 70% volume, though usage time may vary.

To avoid damage, use only the included or recommended accessories. The earbuds automatically shut off after a few minutes of inactivity, with a confirmation message.

Product Details



Legend

- Left Earbud Button
- Left Earbud LED Indicator
- Right Earbud LED Indicator
- Right Earbud Button
- Right Earbud Charging Compartment
- Left Earbud Battery Status Indicator
- Right Earbud Battery Status Indicator
- Type-C Charging Port (Bottom)
- Charging Case Battery Status Indicator
- Left Earbud Charging Compartment

Inside the Box

- Earbuds
- Charging case
- Silicone ear tips (S/M/L)
- Type-C charging cable
- User's manual

Capacitive Buttons

Your earbuds feature capacitive buttons that respond to touch. To perform any of the actions listed below, simply touch the capacitive button gently.

Earbuds On/Off

If the earbuds are charged, they will automatically turn on when removed from the charging case. They will disconnect from the audio source and begin charging when placed back in the case.

Alternatively, when the earbuds are out of the charging case, you can power both off by long-pressing the button until you hear a confirmation message. To turn them back on, long-press each button individually. A confirmation message will be heard.

Pairing the Earbuds to a Phone (first time)

After powering on the earbuds, they will automatically enter pairing mode. The status light will flash blue and red, accompanied by a confirmation message. Open your phone’s BT, and from the list of available devices, select your earbud's model number, which should start with “HS7511”. Once the connection is established, a message

will confirm the successful pairing and the status light will go off.

Track Management

To pause or resume playback of an audio track, press once on either earbud's button. To go to the next track, press the right earbud's button twice. To go to the previous track, press the left earbud's button twice. To adjust the volume, triple-press the left earbud's button to lower the volume or right earbud's button to raise the volume.

Call Management

To answer an incoming call, briefly press either earbud's button and briefly press it again to hang up. Long-press either earbud's button to reject the call.

Smart Assistant (compatible phones)

To wake your smart assistant (e.g., Google Assistant™, Alexa™, Siri ™, or others), press and hold the multifunction button on either earbud for about 1.5 seconds until the assistant appears on your phone. Alternatively, you can use your usual voice command, such as "OK Google."

Features & Technical Specifications

- BT Version: 5.3
- BT profiles: A2DPV1.3, AVRCPV1.6, HFPV1.6 & HSPV1.2
- BT working range (ft): 33
- Capacitive buttons
- Digital battery-level display
- Earbuds charging time (h): 2
- Case charging time (h): 2
- Case charging cycles: 4 (80% efficiency)
- Earbuds playing time (h): 4/20 (combined time)
- Earbuds battery (mAh): Li-ion 30
- Case battery (mAh): Li-ion 300
- Frequency response (Hz): 20 - 20,000
- Impedance (Ω): 16 +/- 5% @ 1mW / 1,000Hz
- Sensitivity (dB): 102 +/- 3 @ 1KHz
- Output power (mW): 50
- Driver diameter (in): 0.4
- Microphone sensitivity (dB): -42 +/-3
- Input power (VDC/A): 5/0.5
- Earbud weight (oz): 0.2 each (1.3 whole set including case)